



Multimedia Speakers
2.0 Audio System with Volume Control
SPSK-201-WD



Technical details:

Output power: 3W x 2
Drive unit: 2.5" x 2
Ratio S/N: $\geq 80\text{dB}$
Frequency: 50-20000Hz
Power input: USB 5V
Sizes: 145 x 70 x 90 mm
Volume control

OPERATION INSTRUCTION

1. Connect USB Cable from speaker to the computer.
2. Connect the 3.5mm cable from speaker to the computer.
3. Play the music, movie or games on the computer.
4. Adjust the volume: raise or lower the volume by adjusting the audio regulator.

First Use of the Device / introduction

Select a proper place for the device. A dry, level and slip-proof surf suitable. Do not place objects (such as vases) on top of the speaker.

Make sure the device is vented sufficiently!

Product Features

Perfect sound with 3D stereo effect. Hot plug, no need any software driver.
Full frequency speaker.

Package Content

Speakers 2 pcs
User Manual 1 pcs

Technical specification

Output power: 2*3W
Ratio S/N: $\geq 80\text{Db}$
Frequency response: 50Hz - 20000Hz Power input: USB 5V

General Safety Guidelines

Thank you for purchasing our 2.0 speaker system. With high quality design of our products, you can enjoy the real sound effect in various applications and environments, and feel the charms that field sound brings. Elegant and

classic Wood design absorbs sound waves, avoiding noise caused by sound reflection, improving sound quality. Before installing, please read the following instructions carefully. Keep the user manual for your future reference.

To avoid the risk of fire or electric shock, you should not expose the device to rain or humidity. Do not use the device to rain or humidity. Do not use the device near water (e.g. bathroom, swimming pool, humid cellars).

Plug the device only into a properly installed socket. Be sure the device voltage corresponds to the grid voltage.

Avoid covering the device's vent openings.

Do not open the back board arbitrarily for preventing from being electrified or other accidents. In case of repair, submit it to the professional.

Salutary reminder

To extend the service life, avoid distortion and protect your hearing. Do not turn the volume too loud. Do not operate the device on maximum volume. This can cause damage.

Please take off the power immediately once the working unit with any fault, this can protect the speaker unit and other electronic component from damage.

Do not subject the speakers to extreme heat, cold or humidity.

Do not touch the speaker membranes with fingers or objects. This will cause damage to the membranes.

Cut power off and take the plug away from the connector when the system is not on work.

In case of cleaning, please use the dry and soft cloth.

Disposing of the product. Do not dispose of the product or other electronic components with your household waste. Use only specialized electronic waste collection centers.



WASTE DISPOSAL:

The adjacent symbol indicates that your product and / or its battery must be disposed of separately from household waste in accordance with local laws and regulations. When this product reaches the end of its life, take it to a collection point designated by the local authorities. For information about the local collection centers, please contact the town hall of your locality or access the page www.ecotic.ro

We hereby declare that our product is in compliance with Directive 2014/30 / EU.

